# NAUTIZ X6
QUICK START GUIDE

handheld

① WHAT'S IN THE BOX

The pictures shown below may differ from the actual products.
To purchase additional or optional products, contact our customer center.

Standard battery

Charging adaptor

Nautiz X6 Main body

Type-C cable

Converter plugs

② YOUR NAUTIZ X6

Earpiece

Front camera

Light sensor

Configurable side button

Volume up

Volume down

Microphone

Speaker

Function Key 1

Power button

Function Key 2

Function Key 3

③ YOUR NAUTIZ X6

Docking port

Rear camera

External antenna port

LED flash

Battery cover lock

TYPE-C interface

④ SIM/MICRO SD CARD

This is how you insert and remove the SIM/micro SD.

SD Card

Sim1

Sim2

⑤ INSERT BATTERY

**To insert the battery**

1. Insert the battery
2. Push the battery lock to the close position
3. Attach the battery cover

Battery lock

⑥ INSERT BATTERY

To insert the battery

4. Push the battery cover lock to the close position

⑦ REMOVE BATTERY

To remove the battery

1. Power off the device before removing the battery
2. Push the battery cover lock to the open position

⑧ REMOVE BATTERY

To remove the battery

3. Detach the battery cover
4. Push the battery lock to the open position
5. Remove the battery

Battery unlock

Google, Android and Google Play are trademarks of Google LLC.

handheld

www.handheldgroup.com

Version 1.0